#### **Feature operation**

| i eature operation    |              |                         |                 |
|-----------------------|--------------|-------------------------|-----------------|
| AutoDial              |              |                         |                 |
| Store                 | AutoDial     |                         | AutoDial        |
| Use                   |              | AutoDial                |                 |
| Display               | Display      | AutoDial                |                 |
| Call Forward          |              |                         |                 |
| Activate              | Fwd          |                         | <b>▶</b> Fwd    |
| Deactivate            | <b>▶</b> Fwd |                         |                 |
| Reinstate             | Fwd          | <b>▶</b> Fwd            |                 |
| View number           | Display      | <b>▶</b> Fwd            |                 |
| Call Pickup           |              | Pickup                  |                 |
| Call Waiting          |              |                         |                 |
| Answer                | (Hold)       | Call Waiting            |                 |
| Return to first call  | (Goodbye)    |                         |                 |
| Conference            | Conf         | 0 0 0<br>0 0 0<br>0 0 0 | ▶ Conf          |
| Handsfree             |              |                         |                 |
| Activate              | (Handsfree)  | (Goodbye) (to           | o end the call) |
| Switch to handset     |              |                         |                 |
| Handset to handsfree  | (Handsfree)  |                         |                 |
| Activate Headset      | (Headset)    | (Goodbye) (to           | o end the call) |
| Hold                  |              |                         |                 |
| Place a call on hold  | (Hold)       |                         |                 |
| Return to a held call |              |                         |                 |
| Last Number Redial    |              |                         |                 |
| Message               |              | ্রি<br>(Msg/Inbox)      |                 |
| Ring Again            |              |                         |                 |
| Activate              | RngAgn       |                         |                 |
| When notified         |              | RngAgn                  |                 |
| Deactivate            | ► RngAgn     |                         |                 |
| Transfer              | Trans        |                         | ▶ Trans         |
| Adjust volume         | (Volume +)   | or (Volume -)           |                 |
| Lawrend               |              |                         |                 |

#### Legend

| J       |   |
|---------|---|
| Icon    | Action  |
| ( )     | Indicates the key cap text label. For example, (Message).     |
|         | Lift the handset, press the line (DN) key or the Handset key. |
| <u></u> | Replace the handset, or press (Goodbye) to end the call.      |

### Legend (continued)

| Legend (continued) |   |  |  |  |
|--------------------|---|--|--|--|
| Icon               | Action  |  |  |  |
|                    | Press a line/feature key.   |  |  |  |
|                    | Dial a number.  |  |  |  |
| ► AutoDial         | An icon flashes when a feature is being programmed.<br>An icon lights steadily when a feature is active.          |  |  |  |
|                    | Press the Services key once for Call Platform features, or press the Services key twice for local phone features. |  |  |  |
| (Z)                | Press the Message/Inbox key.  |  |  |  |
|                    | Press the Up/Down Navigation keys   |  |  |  |
| 4                  | Press the Send/Enter key  |  |  |  |
| 9 1                | Press the <b>Headset</b> key.   |  |  |  |
|                    | Press the <b>Handsfree</b> key.   |  |  |  |
| I &                | Press the Mute (on/off) key.  |  |  |  |
| Ψ                  | Press the <b>Directory</b> key.   |  |  |  |
| 0                  | Press the Quit/Stop key.  |  |  |  |
| Sarvicas and       | d Tolonhono Ontions monus   |  |  |  |

## Services and Telephone Options menus Services menu

| (Services)            |                   | 4             |                              |     |
|-----------------------|-------------------|---------------|------------------------------|-----|
| Note: The Service     | s menu contains t | the Telephor  | ne Options, Password         |     |
| Admin, Virtual Of     | fice, and MG 1000 | DB menus. Th  | hese options are not availab | ıΙε |
| on all Nortel IP Ph   | one 1120E phones  | s. Consult yo | ur system administrator.     |     |
| e following are the r | nost commonly us  | ed options:   |                              |     |

| relephone options if  | iciiu |       |      |       |
|---|-------|-------|------|-------|
| Volume adjustme   | nt    |       |      |       |
| Pick one of: Ringer Handset Listen Handsfree Listen Headset Listen Buzzer | (J    |       | 4    | Quit) |
| Contrast adjustme   | ent   |       |      |       |
| $\bigcirc \bigcirc$   | T)    | Q (Qı | uit) |       |
| Language  |       |       |      |       |
| \rightarrow \frac{1}{2}   | 4     | (Qı   | uit) |       |

**Note**: This language setting controls the language used by features on your phone only. To set the language used elsewhere on your phone, press **Services** twice, select 1. Preferences, and select 2. Language.



**Note**: The **Directory** key provides access to Corporate Directory, Personal Directory, Redial List, and Callers List. For additional information about your IP Phone 1120E, consult the *Nortel IP Phone 1120E User Guide*.

### **Nortel IP Phone 1120E**



www.nortel.com



\*Note: If supported by your server, the Feature Status Lamp provides a user-defined alert. Contact your system administrator to find out if this feature is available for you.

# IP Phone 1120E

For Nortel Communication Server 1000

### Quick Reference Card



Date: January 2006

Document Release: Standard 1.00 Document Number: NN-10300-046 Copyright © Nortel Networks Limited 2006 All rights reserved.

\* Nortel, the Nortel logo, and the Globemark are trademarks of Nortel Networks.